



**SAVE THESE INSTRUCTIONS**



---

### IMPORTANT SAFETY INSTRUCTIONS

1. Read all instructions
2. Do not conceal or extend exposed conductors through a building wall.
3. Do not install this system in wet locations.
4. For low voltage exposed insulated conductor systems required by 30.1(c) do not install any part of this system less than 7 feet (2.2m) above the floor.
5. To reduce the risk of fire and burns, do not install this lighting system where the exposed bare conductors can be shorted or contact any conductive materials.
6. To reduce the risk of fire and overheating, make sure all connections are tight.
7. Do not install any luminaire closer than 6 inches (15.25cm) from any curtain, or similar combustible materials.
8. Turn off electrical power before modifying the lighting system in any way.
9. Wire the remote transformer for the system as described in these instructions.
10. Load the transformer to no more than the maximum rated capacity as specified.
11. This product must be used with the Journée Monrail System only
12. Only used properly specified Journée fixtures with system.
13. The system is UL listed only when all the products used are supplied by Journée Lighting
14. A typical installation is outlined. Specific installation must be in accordance with local electrical code.
15. **This product requires a qualified, licensed electrician to install the system.**

### SAVE THESE INSTRUCTIONS

---





**Detailed Order of Installation: Monopoint Installation**  
REFER TO MONOPOINT INSTALLATION DIAGRAM ON PAGE 1  
(also see installation instructions included with your  
monopoint canopy for detailed figures)

**NOTE: MINIMUM VOLUME OF ELECTRICAL BOX MUST BE  
21.5 CU. IN.**

1. Shut down power to the electrical box.
2. Ground the transformer green wire in accordance with local electrical code.
3. Connect the 120 volt white transformer wire to the neutral power line with a wire nut.
4. Connect the 120 volt black transformer wire to the hot power line with a wire nut.
5. Secure the transformer to the inside of the electrical box with the supplied adhesive strip.
6. Use wire nuts to attach the wires from the canopy to the low voltage wires of the Monopoint Transformer.
7. Place all the wires into the electrical box.
8. Install the Monopoint canopy to the electrical box using the supplied spider plate and screws.
9. Thread a Modular Stem onto any Journ e LED Luminaire.
10. Thread the Modular Stem into the Monopoint Canopy.

### Troubleshooting

- Check the low-voltage side of the transformer with a voltmeter to ensure voltage output is 24 volts.
- Breaker on the main panel tripped
  - Confirm the circuit has not been overloaded.
  - Change the breaker in the panel to an inductive load breaker.
- If the system is still not working, check the basics
  - Check the light switch.
  - Check for loose wire nuts in the j-box and Monopoint Canopy.
  - Make sure the 120 volt side of the transformer is wired correctly.

**SAVE THESE INSTRUCTIONS**

[WWW.JOURNEELIGHTING.COM](http://WWW.JOURNEELIGHTING.COM)

TELEPHONE 800-886-1880 – FAX 800-886-1881

4607 Lakeview Canyon Rd #500 - Westlake Village, CA 91361